



# ECLIPSE

## APPLICATION GUIDE

### Steps:

1. - Prep and Prime the surface as you would for any other paint job.
2. - Apply your choice of base colors (white will product the most dramatic effect).
3. - Reduce the Eclipse 1:1 with Urethane Reducer AMR-2712
4. - Apply 2 to 3 coats until desired effect is achieved. With 10-15 minutes between coats.
5. - Air dry 30 min.
6. -At this time you can either continue with Candies etc. or move on to the final clear.
7. -Topcoat with our recommended clear coat (Speed Clear) as this clear contains a very strong UV Blocker to insure long life of the Eclipse basecoat.