



SOFT TOUCH PREVAL KIT

Kit Includes:

(25sqft Kit)

- 1 Preval Sprayer
- 1 Preval 6oz. Container
- 1 ST2010 4oz.
- 1 ST2011 3oz.
- 1 ST2012 1oz.
- 1 Mixing Cup
- 1 Paper Strainer
- 1 Wood Stirrer

INSTRUCTIONS

1. **Preparation of the Surface:** Prepare and prime the surface as you would any normal paint job.
2. **Base Color:** Apply 2-3 medium wet coats of basecoat of your preference, make sure you have a uniform coverage. Let the basecoat flash off for 15-20 minutes.
3. **Soft Touch Clear Mixing:** In the mixing cup pour the 4oz. of clear (ST2010), 1oz. of hardener (ST2012), 3oz. of thinner (ST2011) and mix it well with the wood stirrer until you have a uniform blend. Using the strainer transfer the mixture from the mixing cup, to the preval container, and then attach the preval unit.
4. **Application:** Apply 3 wet coats with 5-10 minutes flash time in between coats. Let it dry 12-24 hours before handling it.
DONOT SHAKE PREVAL CAN, USE AT 45° ANGLE, DONOT FLIP PREVAL CAN.
5. If you are going to apply Soft Touch to a surface that is already painted with OEM or aftermarket finish, SKIP steps 1 and 2. Sand the surface with 800-1000 wet sand paper, wash it off with soap and water and let it dry. Clean the surface with prep-cleaner or you can use alcohol to remove any contamination on the surface. Proceed to steps 3 and 4.

THIS IS A ONE TIME USE KIT, ONCE YOU FINISH THE PROJECT LET ANY LEFT OVER MATERIAL DRY (HARDEN) AND DISCARD EVERYTHING.

1213 E. 58th Pl. Los Angeles, CA 90001 Tel. 323-515-1100 Fax. 323-515-1089