



Easy Chrome (w/o Spray Cans)

Application Guide

Pre-Application:

To begin the Easy Chrome Spray process, your part must be prepped and ready for application. Preparation includes: Sanding, Buffing and Priming. Primer can be any automotive grade primer.

Applying Easy Chrome BASECOAT:

When your part is ready for application you will begin with the Easy Chrome **BASECOAT** at an approximate distance of 8" away from surface. Spraying 2 medium coats until you part is fully covered.

Approximate dry time 1 hour at 70°F.

*****THIS BASECOAT WILL HAVE A HIGH GLOSS FINISH**

Applying Easy Chrome:

After your part has fully dried, continue to apply Easy **CHROME** at an approximate distance of 8" away from surface. **Lightly Dust/Brush on 1 coat of Easy CHROME**, wait a few seconds until you see chrome. Continue to **Lightly Dust/Brush 1 more coat of Easy CHROME** waiting the same amount of time between sprays until your part is fully covered.

******* DO NOT OVER APPLY EASY CHROME AS THIS WILL RESULT IN DULL FINISH**

Allow 4 hours Air Dry Time at room temperature

After Easy Chrome has dried, **LIGHTLY** polish surface using the **INLCLUDED** Polish Cloth in your kit to remove excess dust.

If steps are followed properly, you should have successfully completed your application.

******** For Technical Support Call 323-515-1100 Email info@alsa-refinish.com