



# Easy Chrome New Clear Basecoat

## Application Guide

### **Pre-Application:**

To begin the Easy Chrome Spray process, your part must be prepped and ready for application. Preparation includes: Sanding, Buffing and Priming. Primer can be any automotive grade primer.

### **Applying Easy Chrome BASECOAT:**

When your part is ready for application you will begin with the Easy Chrome **BASECOAT** at an approximate distance of 8" away from surface. Spraying 2 medium coats until your part is fully covered.  
Mix Hardener provided into Basecoat 4-1

Approximate dry time 3hrs. at 75°F

**\*\*\*THIS BASECOAT WILL HAVE A HIGH GLOSS FINISH**

### **Applying Easy Chrome:**

After your part has fully dried, continue to apply Easy **CHROME** at an approximate distance of 8" away from surface. **Lightly Dust/Brush on 1 coat of Easy CHROME**, wait a few seconds until you see chrome. Continue to **Lightly Dust/Brush 1 more coat of Easy CHROME waiting the same amount of time between sprays** until your part is fully covered.

**\*\*\*\*\* DO NOT APPLY TWICE OR OVER APPLY EASY CHROME AS THIS WILL RESULT IN DULL MILKY FINISH**

Allow 4hr Air Dry Time at approximate temperature of 75°F

After Easy Chrome has dried, **LIGHTLY** polish surface using the **INCLUDED** Polish Cloth in your kit to remove excess dust.

**Apply Topcoat Directly, allow to dry 2 hours**  
(Topcoat is optional)

**You can also bake it in an oven,**

**1<sup>st</sup> allow basecoat to dry on its own for 30 minutes, then you can put it in the oven for 1 hour , same with Basecoat, Easy Chrome and Topcoat**

If steps are followed properly, you should have successfully completed your application.

**\*\*\* For Technical Support Call 323-515-1100 Email [info@alsa-refinish.com](mailto:info@alsa-refinish.com)**